



Uključivanje/isključivanje WLAN-a svi uređaji

SE515

Pristupiti routeru sa 192.168.1. unijeti lozinku, ako lozinka nije mjenjana samo Login kliknemo.




Odabrati opciju Advanced Setup.





U izborniku sa lijeve strane odabrati Wireless.



Sa desne strane pored opcije Wireless odabrati ON ili OFF te u donjem desnom uglu kliknuti na Apply.



SE555

Pristupiti routeru sa 192.168.1.1 (192.168.2.1 bez IPTV podrške), unijeti lozinku, ako lozinka nije mjenjana najčešće je 0000 ili bez lozinke samo OK kliknemo.

Gigaset SE555 WLAN dsl



SIEMENS

Odabrati Advanced Setup.

Gigaset SE555 WLAN dsl



SIEMENS

Iz izbornika sa lijeve strane odabrati Wireless Network.



Gigaset SE555 WLAN dsl



SIEMENS

Sa desne strane će nam se pojaviti ON i OFF. Odabrati željenu opciju. ON za paljenje WLAN-a ili OFF za gašenje.

Gigaset SE555 WLAN dsl




SIEMENS




D-LINK 684T

Ulogirati se na D-link sa 192.168.1.1. Pod korisničko ime i lozinku unjeti admin i 0000 ili admin i admin.





Odabrati stavke kako je prikazano na slici (crvene strelice).





Aktivirati WLAN stavljanjem kvačice ili deaktivirati micanjem kvačice na opciju Enable AP. Potom kliknuti na gumb Apply.

Home Advanced Tools Status Help

Wireless Settings

These are the wireless settings for the AP(Access Point) Portion.

☒ Enable AP

SSID:

Channel:


Security: ☒ None ☐ WEP ☐ WPA

Please save and reboot the device to take effect !

☒ Apply ☐ Cancel ☐ Help



Za spremanje postavki odabrati Tools (1), zatim kliknuti System (2) i odabrati Save and Reboot (3).





ZyXEL P-660-T3 (63)


Pristupiti routeru na adresi 192.168.1.1, u lozinku unijeti 0000 i kliknuti Log In.

Prestige 660HW-63/67

Enter Password and click Login.

Password:

U stupcu Advanced Setup odabrati Wireless LAN.





Aktivirati WLAN stavljanjem kvačice ili deaktivirati WLAN micanjem kvačice sa opcije Enable Wireless LAN te potom kliknemo Apply.

ZyXEL
TOTAL INTERNET ACCESS SOLUTION

SITE MAP HELP

Main Menu

Advanced Setup

- Password
- LAN
- Wireless LAN
- WAN
- NAT
- Dynamic DNS
- Time and Date
- Firewall
- Content Filter
- Remote Management
- UPnP
- Logs
- Media Bandwidth Mgmt.

Logout

Wireless LAN- Wireless

☒ Enable Wireless LAN

☒ Enable Wireless g+

802.11 Mode: Mixed

ESSID: ZyXEL

Hide ESSID: No

Channel ID: Channel01 2412MHz

☒ RTS/CTS Threshold: 4096 (0 ~ 2432. if 802.11g+ enable, it should only be 4096)

☒ Fragmentation Threshold: 4096 (256 ~ 2432. if 802.11g+ enable, it should only be 4096)

Passphrase: Generate

WEP Encryption: Disable

64-bit WEP: Enter 5 characters or 10 hexadecimal digits ("0-9", "A-F") preceded by 0x for each Key(1-4).
128-bit WEP: Enter 13 characters or 26 hexadecimal digits ("0-9", "A-F") preceded by 0x for each Key(1-4).
256-bit WEP: Enter 29 characters or 58 hexadecimal digits ("0-9", "A-F") preceded by 0x for each Key(1-4).

☒ Key1
☐ Key2
☐ Key3
☐ Key4

Back Apply




ZyXEL P-660-T3 (63)

Pristupiti routeru na adresi 192.168.1.1, u lozinku unijeti 0000 i kliknuti Log In.


Odabrati Go to Advanced Setup (1) i zatim kliknuti na Apply (2).



Sa lijeve strane odaberete Network (1) i odaberete podopciju Wireless LAN (2).




Aktivirati WLAN postavljanjem kvačice ili deaktivirati WLAN micanjem kvačice sa opcije Active Wireless LAN (1) te potom kliknuti gumb Apply (2).





THOMSON SPEEDTOUCH WL780

Pristupiti routeru na adresi 192.168.1.1, u korisničko ime unijeti user a u polje password 0000
Pod Home Network odabrati Wireless.



Kliknuti na opciju Configure u gornjem desnom uglu prozora.





Aktivirati WLAN stavljanjem ili deaktivirati WLAN micanjem kvačice sa opcije Interface Enabled.

THOMSON ST780

[USER] Overview | Details | Configure |

Home > Home Network > Interfaces > WLAN: Speed Touch

Wireless Access Point - Speed Touch

Configuration

Interface Enabled: ☒ 

Physical Address: 00:90:D0:EB:79:E7

Network Name (SSID): Speed Touch

Interface Type: 802.11b/g

Actual Speed: 54 Mbps

Channel Selection: Automatic

Region: Europe

Na dnu stranice kliknuti na gumb Apply.



SIEMENS SX763 WLAN

Pristupiti routeru na adresi 192.168.1.1, u lozinku unijeti admin i zatim kliknuti OK.

Gigaset SX763 WLAN dsl

Logon

?

Welcome

You can use this interface to administer your device. For your security, the configuration program is protected with a password.

Please enter your password:

OK

SIEMENS

Pojavljuje se upozorenje da nije promjenjena početna lozinka, samo kliknemo OK.

Security Advice

Your device and your network might be at risk:


- System password not changed
- Identification of your wireless network visible or not changed
- Encryption for your wireless network not activated

It is recommended to run the Security Setup Wizard or change the Advanced Settings to fully secure your device.


OK



Odabrati Advanced Setup kako je pokazano na slici.



Sa lijeve strane odabrati Wireless Network (1), sa desne strane pored opcije Wireless Network odabrati ON ili OFF (2) te na kraju kliknuti OK (3).



The screenshot shows the Thomson Gateway web interface. At the top left, there's a pink navigation bar with four buttons: "Thomson Gateway", "Broadband Connection", "Toolbox", and "Home Network". The main content area has a header with "[administrator]" and "Home" links. Below this, there are three sections:

- Thomson Gateway**: Includes an icon of a gateway device and a list with "Information". To the right, it displays "Product Name: TG782" and "Software Release: 8.6.Q.1".
- Broadband Connection**: Includes an icon of a globe with arrows. It shows "Internet:" as "Connected" with a "Disconnect" button.
- Toolbox**: Includes an icon of a toolbox. It lists several features, all of which are "Disabled": "Remote Assistance:", "Game & Application Sharing", "Firewall:", "Parental Control", "Telephony:", and "Address Book:".

At the bottom, there's a section for **Home Network** with an icon of a room and a "Wireless:" status indicator showing "off".



Kliknuti na opciju Configure u gornjem desnom uglu prozora.

THOMSON TG782

T · · Com · ·

[administrator] Overview | Details | **Configure** | Help

Home > Home Network > Interfaces > WLAN: Nedostupna_mreza

Wireless Access Point - Nedostupna_mreza

- Configuration

Interface Enabled:	Yes
Physical Address:	00:24:17:3E:1A:E8
Network Name (SSID):	Nedostupna_mreza
Interface Type:	802.11b/g
Actual Speed:	54 Mbps
Band:	2.4G Hz
- Security

Allow New Devices:	New stations are allowed (automatically)
Security Mode:	WEP

Aktivirati WLAN stavljanjem ili deaktivirati WLAN micanjem kvačice sa opcije Interface Enabled.

THOMSON TG782

T · · Com · ·

[administrator] Overview | Details | **Configure** | Help

Home > Home Network > Interfaces > WLAN: Nedostupna_mreza

Wireless Access Point - Nedostupna_mreza


- Configuration

Interface Enabled:	☒
Physical Address:	00:24:17:3E:1A:E8
Network Name (SSID):	Nedostupna_mreza
Interface Type:	802.11b/g
Actual Speed:	54 Mbps
Band:	2.4G Hz
Channel Selection:	Automatic
Region:	Europe
Channel:	1
Allow multicast from Broadband Network:	☒



ADB (Pirelli) P.RG A4202N

- Otvorite web preglednik (npr. Internet Explorer), upišite adresu 192.168.1.1 i pritisnite Enter na tipkovnici.
- U otvorenom prozoru pod Username upišite: user, a pod Password upišite podatak SN koji se nalazi na naljepnici sa stražnje strane modema.





- S desne strane odaberite WiFi ikonu. Nakon toga u polju Name (SSID) upišite željeni naziv bežične mreže.



- Da biste zaštitili bežičnu mrežu, u padajućem izborniku Security Mode odaberite WPA-WPA2. Nakon toga u polju WPA Passphrase upišite željenu lozinku i na kraju pritisnite Apply.

The screenshot shows the web interface of a Residential Gateway (ADB Broadband) accessed via a Windows Internet Explorer browser. The address bar shows the URL `http://192.168.1.1/ui/dboard?editx=wifi&of=1`. The interface has a red header with the Hrvatski Telekom logo and navigation tabs for "Basic Mode" and "Advanced Mode". The "Advanced Mode" tab is selected.

On the left side, there is a "Device Summary" panel showing various system information:

- Device Summary:**
 - Firmware Version: PRGA4202N_HTC_2.1.1.0001 - main
 - Platform Version: 2.1.0.0040
 - Hardware Version: BCM6362
 - Uptime: 52m 7s
- Internet Connection:** Not Connected
 - Type: PPP - Ethernet over ATM, 0/33
 - Disable button
- DSL Line:** Down
- WiFi:** Down
 - Name (SSID): adbb-prod
 - Security: WPA2, AES
- LAN IP Address:** 192.168.1.1
 - DHCP Server: Enabled
 - Min Address: 192.168.1.100
 - Max Address: 192.168.1.150
- Ethernet Ports:** 1 2 3 4 5
- Voice Lines:** 1 2

The main content area is titled "Wireless Access Point" and contains the following settings:


- Status:** Down
- Enable Access Point:** ☐ Yes ☒ No
- Name (SSID):** adbb-prod
- Wi-Fi Security Settings:**
 - SSID Broadcast:** ☒ Yes ☐ No
 - AP Isolation:** ☐ Yes ☒ No
 - WiFi Segregation:** ☐ Yes ☒ No
 - Security Mode:** WPA2 (dropdown menu)
 - Encryption Mode:** AES (dropdown menu)
 - WPA Passphrase:** [masked with dots] ☐ Show password
- Wi-Fi Protected Setup:**
 - WPS Enabled:** ☐ Yes ☒ No

At the bottom of the configuration panel, there is an "Advanced Configuration" link and two buttons: "Apply" and "Close". The footer of the page reads "Copyright © 2010-2012 ADB Broadband S.p.A.".



ZTE 931 VII

- Otvorite web preglednik (npr. Internet Explorer), upišite adresu 192.168.1.1 i pritisnite Enter na tipkovnici.
- U otvorenom prozoru pod Username upišite: user, a pod Password upišite podatak SN koji se nalazi na naljepnici sa stražnje strane modema.





Ručno podešavanje bežične mreže (WLAN):

- u otvorenom prozoru odaberite Network -> WLAN -> Basic i u otvorenom prozoru u polju Wireless RF Mode odaberite Enabled, a zatim pritisnite Submit.

Status	Path:Network-WLAN-Basic Logout	
Network		
WAN		
WLAN		
Basic		
SSID Settings		
Security		

Wireless RF Mode

Enable Isolation ☐

Mode

Country/Region

Band Width

- Nakon toga odaberite Network -> WLAN -> SSID Settings i u polju SSID Name upišite željeni naziv bežične mreže, a zatim pritisnite Submit.

Status	Path:Network-WLAN-SSID Settings Logout	
Network		
WAN		
WLAN		
Basic		
SSID Settings		
Security		
Access Control List		
Associated Devices		
WMM		
WiFi Restrictions		
WPS		
LAN		

Choose SSID

Hide SSID ☐

Enable SSID ☒

Enable SSID Isolation ☐

Maximum Clients (1 ~ 32)

SSID Name (1 ~ 32 characters)

Priority



- Da biste zaštitili bežičnu mrežu, obavezno odaberite Network -> WLAN -> Security i u polju Authentication Type preporučujemo odabrati WPA/WPA2-PSK. Nakon toga u polju WPA Passphrase upišite lozinku. Na kraju pritisnite Submit.

Status	Path:Network-WLAN-Security	Logout
Network		
WAN		
WLAN		
Basic		
SSID Settings		
Security	Choose SSID SSID1 Authentication Type WPA/WPA2-PSK WPA Passphrase uNJXXHmT (8 ~ 63 characters) WPA Group Key Update Interval 600 sec WPA Encryption Algorithm TKIP+AES	
Access Control List		
Associated Devices		
WMM		